



We take children's safety seriously. Children not following the safety rules should be asked to leave the bounce house or take a "time out"....

**Do not enter the inflatable unless an attendant is present**



NO Shoes

NO Eyeglasses

NO Belt buckles

NO Jewelry

NO Cell phones

NO Food or Drinks

NO gum

**NO WATER or sprays**

NO Silly String or like products (it will eat through the material)

NO Sharp Objects

**All Riders MUST empty their pockets BEFORE entering Ride**



Riders should be of the same weight & size. (Adults & older kids should not ride with smaller children)

Enter ride in an orderly manner. (One at a time)

No Jumping on the "pillow" leading into the unit. (The part of the inflatable that helps you up into the unit)

No Flips or somersaults (landing the wrong way could break your neck or other bones.)

No piling on or wrestling others.

NO Rough Play!

Do not bounce against the side or near the doorway. Keep hands off the net.

If you want to come out, ask the attendant to open the zipper, and exit slowly.

If the inflatable begins to lose air, make your way out the door.



Keep all animals away from the unit. They should NEVER come within 20 feet of the inflatables.

Smokers should also stay 20 feet away, as the cherries will blow several feet.

In the event of rain, remove participants, have them stand away at a safe distance, turn off the blower and unplug it from the outlet, along with any extension cords, and put the blower under cover or indoors until the rain stops. Keep the unit covered with a tarp to keep the water out, and keep the children away. Do NOT WALK ON THE UNIT or allow kids to play on it while it is deflated.

*\*YOU ARE responsible for any damages to the equipment we provide for rental.*